



Shipping mark item number+description	Item number	Spare Part Letter	Spare Part Code	SAP spare part code	Description English	Quantity	Packed in carton	Picture	SAP Compatibility	Compatibility
41347-G-BBQ 6+1 RVS Prom										
	41347	A	41347R.A	P02100713	Hood silver	1	A			41346, 41345, 41348
	41347	B	41347R.B	P02100687	Body silver	1	A			41341, 41342, 41348
	41347	C	41347R.C	P02100684	Hood Hinge silver	2	A			41340, 41341, 41342, 41345, 41346, 41347, 41348
	41347	D	41347R.D	P02100688	Body Hinge silver	2	A			41342, 41341, 41348
	41347	E	41347R.E	P02100635	wheel Axle	2	A			41344, 41343, 41346, 41345, 41348, 41337, 41338, 41339, 41340, 41341, 41342
	41347	F	41347R.F	P02100636	Hinge Clip	4	A			41344, 41343, 41346, 41345, 41348, 41337, 41338, 41339, 41340, 41341, 41342
	41347	G	41347R.G	P02100637	Hood Handle	3	A			41344, 41343, 41346, 41345, 41348, 41337, 41338, 41339, 41340, 41341, 41342
	41347	H	41347R.H	P02100638	Cooking Grid	1	A			41344, 41343, 41346, 41345, 41348, 41337, 41338, 41339, 41340, 41341, 41342
	41347	I	41347R.I	P02100639	Warming Rack	1	A			41344, 41343, 41346, 41345, 41348, 41337, 41338, 41339, 41340, 41341, 41342

41347	J	41347R.J	P02100640	Main Burner	6	A		41344, 41343, 41346, 41345, 41348, 41337, 41338, 41339, 41340, 41341, 41342
41347	K	41347R.K	P02100714	Control Panel silver	1	A		41345, 41346, 41348
41347	L	41347R.L	P02100708	Ignition Valve	1	A		41343, 41345
41347	M	41347R.M	P02100709	Valve	5	A		41343, 41345
41347	N	41347R.N	P02100644	Knob	7	A		41344, 41343, 41346, 41345, 41348, 41337, 41338, 41339, 41340, 41341, 41342
41347	O	41347R.O	P02100710	Flame Tamer W5.7xL33.3cm	6	A		41344, 41343, 41346, 41345, 41348, 41337, 41338, 41339, 41340, 41341, 41342
41347	P	41347R.P	P02100646	Thermometer	1	A		41344, 41343, 41346, 41345, 41348, 41337, 41338, 41339, 41340, 41341, 41342
41347	Q	41347R.Q	P02100689	Side Table silver	1	A		41348, 41341, 41342
41347	R	41347R.R	P02100690	Side Burner Table silver	1	A		41348, 41341, 41342
41347	S	41347R.S	P02100649	Side Burner Rack	1	A		41344, 41343, 41346, 41345, 41348, 41337, 41338, 41339, 41340, 41341, 41342

41347	T	41347R.T	P02100650	Side Burner	1	A		41344, 41343, 41346, 41345, 41348, 41337, 41338, 41339, 41340, 41341, 41342
41347	U	41347R.U	P02100651	Side Valve	1	A		41343, 41345, 41337, 41339, 41341
41347	V	41347R.V	P02100652	Ignition Wire	1	A		41344, 41343, 41346, 41345, 41348, 41337, 41338, 41339, 41340, 41341, 41342
41347	W	41347R.W	P02100653	Drip Cup Hook	1	A		41344, 41343, 41346, 41345, 41348, 41337, 41338, 41339, 41340, 41341, 41342
41347	X	41347R.X	P02100654	Drip Cup	1	A		41344, 41343, 41346, 41345, 41348, 41337, 41338, 41339, 41340, 41341, 41342
41347	Y	41347R.Y	P02100655	Metal Hose	1	A		41344, 41343, 41346, 41345, 41348, 41337, 41338, 41339, 41340, 41341, 41342
41347	Z	41347R.Z	P02100691	Left Leg silver	1	A		41348, 41341, 41342
41347	AA	41347R.AA	P02100692	Right Leg silver	1	A		41348, 41341, 41342
41347	AB	41347R.AB	P02100693	Bottom Panel silver	1	A		41348, 41341, 41342
41347	AC	41347R.AC	P02100694	Rear Bracket silver	1	A		41348, 41341, 41342

41347	AD	41347R.AD	P02100695	Side Panel silver	2	A			41348, 41341, 41342
41347	AE	41347R.AE	P02100686	Door silver	2	A			41345, 41346, 41348, 41339, 41340, 41341, 41342
41347	AF	41347R.AF	P02100662	Door Axle	2	A			41344, 41343, 41346, 41345, 41348, 41337, 41338, 41339, 41340, 41341, 41342
41347	AG	41347R.AG	P02100696	Door Bracket silver	2	A			41337, 41338, 41339, 41340, 41348
41347	AH	41347R.AH	P02100664	Manget	2	A			41344, 41343, 41346, 41345, 41348, 41337, 41338, 41339, 41340, 41341, 41342
41347	AI	41347R.AI	P02100665	Wheel	2	A			41344, 41343, 41346, 41345, 41348, 41337, 41338, 41339, 41340, 41341, 41342
41347	AJ	41347R.AJ	P02100666	Wheel Axle	2	A			41344, 41343, 41346, 41345, 41348, 41337, 41338, 41339, 41340, 41341, 41342
41347	AK	41347R.AK	P02100667	Tool Hook	3	A			41344, 41343, 41346, 41345, 41348, 41337, 41338, 41339, 41340, 41341, 41342
41347	AL	41347R.AL	P02100697	M6x10 Screw	36	A			41348, 41341, 41342
41347	AM	41347R.AM	P02100698	M3x10 Screw	2	A			41348, 41341, 41342

41347	AN	41347R.AN	P02100699	M3 Nut	2	A			41348, 41341, 41342
41347	AO	41347R.AO	P02100700	M5x10 Screw	14	A			41348, 41341, 41342
41347	AP	41347R.AP	P02100701	M5 Nut	8	A			41348, 41341, 41342
41347	AQ	41347R.AQ	P02100702	M6*25 Screw	6	A			41348, 41341, 41342
41347	AR	41347R.AR	P02100703	M6 Nut	6	A			41348, 41341, 41342
41347	AS	41347R.AS	P02100704	M4x10 Screw	2	A			41348, 41341, 41342
41347	AT	41347R.AT	P02100705	M4 Nut	1	A			41348, 41341, 41342
41347	AU	41347R.AU	P02100677	Screw Driver	1	A			41344, 41343, 41346, 41345, 41348, 41337, 41338, 41339, 41340, 41341, 41342